



External



- |                   |                               |
|-------------------|-------------------------------|
| 1 Food Dispenser  | 6 Autobasket Indicator Lights |
| 2 Panels          | 7 Autobasket Handoff Rack     |
| 3 Barrier Doors   | 8 Emergency Stop Button       |
| 4 Indicator Light | 9 Go Button                   |
| 5 Touchscreen     |                               |

Internal



- |                        |                    |
|------------------------|--------------------|
| 1 Main Electronics Box | 6 Fryer Shelf Rack |
| 2 Transformer          | 7 Fryer Shelf      |
| 3 Frame                | 8 Fryer            |
| 4 Dispenser Elevator   | 9 Hot Hold Chute   |
| 5 Robot Arm            |                    |

Before You Begin

|   |                                                       |                     |
|---|-------------------------------------------------------|---------------------|
| 1 | Start Flippy on Touchscreen                           |                     |
| 2 | Turn on the Fryers                                    |                     |
| 3 | Load Dispenser<br>(see <i>separate instructions</i> ) | 4 Place the Baskets |
| 5 | Attach the Hot Hold Chute                             |                     |
| 6 | Place the Catch Pans                                  |                     |

A photo showing a person's hands loading a white container with french fries. The container is labeled 'TAYLOR'.

A photo showing two metal baskets being placed into a fryer. A green arrow indicates the direction of movement.

A 3D rendering showing a metal chute being attached to a fryer. A green arrow indicates the direction of movement.